

BENTLEY - all models					
LTR	kW	ENGINE	DATE	MM	TUNING
BENTLEY Brooklands					
7,0	165kW	L 410 I	09.92-	1,1	DOR17LGS
BENTLEY Continental					
6,8		OHV V8	07.84-	0,8	
BENTLEY Corniche					
6,8			03.71-06.84	0,8	
BENTLEY Mulsanne Turbo					
6,8		OHV V8	04.82-09.85	0,8	
6,8	232kW	OHV V8	10.86-05.90	0,8	
BENTLEY Turbo Limousine					
6,8	230kW	OHV V8	03.85-03.88	0,8	
BENTLEY Turbo R					
6,8	232-240kW	OHV V8	11.91-03.93	1,1	DOR17LGS